



Superb Charger SC4

User Manual

- English
 - Español
- Deutsch Français
- Русский · 日本語
- Română
- 简体中文



只要用 (English) IMPORTANT NOTICE CONCERNING QWARRANTY SERVICE

Thank you for purchasing! Before using this charger, please find your verification code on the package box, and go to http://charger.nitecore.com/validation (or scan the QR code beside the verification code to visit on your mobile phone). Type in your verification code and personal information as required, and submit the page. After verification. Nitecore will send you a warranty service email. This email and your registration email address are essential to your possible warranty application. Before you complete the warranty service registration, you cannot enjoy our warranty service for your purchase.

(Español) AVISO IMPORTANTE RELATIVO AL CONTRACTOR DE GARANTÍA

iGracias por su compra! Antes de usar este cargador, busque el código de verificación en el empague del producto y diríjase a http://charger.nitecore.com/validation (o escanee el código QR junto al código de verificación para ir al sitio web en su celular). Escriba su código de verificación e información según sea necesario y envíe la información. Después de la verificación, Nitecore le enviará un correo electrónico de servicio de garantía. Este correo electrónico y su dirección de correo electrónico de registro son esenciales para su posible solicitud de garantía. Antes de completar el registro del servicio de garantía, no podrá disfrutar de nuestro servicio de garantía para su producto.

即即(Deutsch) WICHTIGER HINWEIS ZUR GARANTIE 한QSERVICE

Danke für Ihren Einkauf! Bevor Sie dieses Ladegerät verwenden, finden Sie Ihren Bestätigungscode auf dem Paketkasten und gehen Sie zu http://charger.nitecore.com/validation (oder scannen Sie den QR-Code neben dem Bestätigungscode, um auf Ihrem Mobiltelefon zu besuchen). Geben Sie Ihren Bestätigungscode und Ihre persönlichen Daten nach Bedarf ein und senden Sie die Seite ein. Nach der Bestätigung sendet Ihnen Nitecore eine Garantie-Service-E-Mail, Diese E-Mail und Ihre Registrierungs-E-Mail-Adresse sind für Ihre mögliche Garantieanwendung unerlässlich. Bevor Sie die Garantie-Service-Registrierung abschließen, können Sie unseren Garantie-Service für Ihren Kauf nicht genießen.

原理 (Francais) AVIS IMPORTANT CONCERNANT VOTRE SERVICE 配口E GARANTIE

Merci d'avoir effectué un achat! Avant d'utiliser ce chargeur, veuillez trouver votre code de vérification sur la boîte et allez sur http://charger.nitecore.com/validation (ou scannez le code QR à côté du code de vérification sur votre téléphone mobile). Saisissez votre code de vérification et vos informations personnelles, et soumettre votre inscription. Après vérification, Nitecore vous enverra un courrier électronique de garantie. Cet e-mail et votre adresse e-mail d'inscription sont essentiels à votre demande de garantie. Avant d'effectuer l'enregistrement du service de garantie, vous ne pouvez pas profiter de notre service de garantie pour votre achat.

回郊 (Русский) ВАЖНОЕ СООБЩЕНИЕ ОТНОСИТЕЛЬНО ПО ГАРАНТИЙНОГО ОБСЛУЖИВАНИЯ

Спасибо за сделанную Вами покупку! Перед использованием данного зарядного устройства просьба найти на упаковочной коробке свой проверочный код и пройти по ссылке http://charger.nitecore.com/ validation (или отсканируйте двумерный штрих-код рядом с проверочным кодом для внесения в свой мобильный телефон). Внесите свой проверочный код и персональную информацию так, как это указано выше, и вышлите эту страницу на наш адрес. После проверки «Найткор» вышлет Вам электронное письмо относительно гарантийного обслуживания. Это электронное письмо и Ваш зарегистрированный адрес электронной почты важны для возможного предоставления Вам гарантийного обслуживания. Если вы не выполните регистрацию в отношении гарантийного обслуживания, мы, к сожалению, не сможем предоставить Вам гарантийное обслуживание в связи с Вашей покупкой.

□烈 (日本語) 保証サービスに関する里安なの知りに □ ○ このたびは本製品をご購入いただきありかとうございます。製品をご使用になる前に帰証サービスへの 登録をお願いいたします。http://charge.nitecore.com/validationにアッセスするか、携帯電話で確 ・ できっよいり、歯にな場の認証コードとお客様の情報を送信ください。弊社に 温寒をの調かったとます。 mup/charget.miecore.com/vandation にノノゼスするか、病命電影で 認コ・ドの横にある OR コードをスキャンし、相に認識の認立コードとお書談の解を送信となった。 弊社に て 確認後、保証サービスメールをお送り致しします。この電子メールと登録いただいた電子メールアドレスは、 保証を受けると必要になりますので大切に保管ください、保証サービスに整線されない場合は、ませの保証 サービスを受けることはできませんのでご了承ください。

□했고 (한국어) 애프터 서비스의 중요 내용 □IQ 본 상품을 구매해 주신 분들께 감사드립니다. 본 상품을 사용하시기 전에 결포장의 QR 코드를 스캔하 시거나 http://charger.nitecore.cn/validation 에 방문하여 정품 여부 확인 및 인증을 하시기 바랍니다. 정품 인증을 성공적으로 진행하신 후 나이트코어에서 발송되는 증빙 메일을 받으십시오.. 이 자료는 안전성 보 증 서비스를 받으실 수 있는 자료입니다 . 애프터 서비스 신청을 하지 않으면 , 추후 애프터 서비스를 받을 수 없

県課(Română) ANUNŢ IMPORTANT PRIVIND SERVICIUL QDE GARANȚIE

Vă mulțumim pentru achiziționarea acestui produs! Înainte de a utiliza acest încărcător, vă rugăm să găsiți codul de verificare pe cutia pachetului, și apoi sa vizitati pagina http://charger.nitecore.com/validation (sau scanați codul QR de lângă codul de verificare pentru a versiunea mobile). Introduceti codul de verificare și informațiile personale solicitate pentru inregistrare. După verificare, Nitecore vă va trimite un e-mail continand certificatul de garantie al produsului achizitionat. Continutul acestui e-mail si adresa de e-mail cu care y-ati inregistrat sunt esentiale si vor fi solicitate in cazul in care veti inainte cereri in garantie. Înainte de a finaliza înregistrarea pentru service în garanție, nu vă puteți bucura de serviciul de garanție oferit pentru produsul achizitionat.

(简体中文) 售后服务的重要提示

服务的重要凭证。如不进 行售后服务申请,将不能享有该产品的保固服务。

(English) Superb Charger SC4 User Manual

Features

- Maximum charging speed up to 3000mA
- Charging current from 300mA-3000mA is manually selectable.
- Compatible with 1.2V. 3.7V. 4.2V. 4.35V batteries
- High-definition color LCD screen displays charging parameter in real time
- · Utilizes energy saving function
- Charging program optimized for IMR batteries
- Automatically identifies battery type and selects appropriate charging voltage and current.
- Capable of manually choosing charging voltage for LiFeP04 battery (3.7V) and Li-ion battery (4.35V).
- · Automatically detects small capacity battery and selects appropriate charging current.
- Canable of charging four batteries simultaneously
- Independently controls and charges each slot
- Integrated USB port compatible with all USB devices Automatically stops charging upon charging completion
- Reverse polarity protection and short circuit prevention
- Li-ion battery restoration
- Overtime charging protection
- Built-in temperature monitor to prevent overheating
- · Automatically detects internal resistance
- . Made from fire retardant / flame resistant PC material · Designed for optimal heat dissination
- Certified by RoHS CE ECC and CEC
- Insured worldwide by Ping An Insurance (Group) Company of China, Ltd.

Specifications

Input Voltage:

AC 100-240V 50/60Hz 1A (MAX) 40W

DC 12V 3A

Output voltage 4.35V±1% / 4.2V ±1% / 3.7V ±1% / 1.48V ±1%

HCR. 5V+5% 2 1A MAY Output current: 3A*2 MAX 1 5A*4

Compatible with Li-ion/IMR/LiFePO4

10440, 10500, 12340, 12500, 12650, 13450, 13500, 13650, 14350, 14430, 14500, 14650, 16500, 16340(RCR123), 16650, 17350, 17500, 17650, 17670, 18350, 18490, 18500, 18650, 22500, 22650, 25500, 26500, 26650

Ni-MH(NiCd): AA, AAA, AAAA, C, D

6.50" × 4.33" × 1.77" (165mm×110mm×45mm) Weight: 13.59oz (385g) (without batteries and power cord)

Operating Instructions

Connect to power source: connect the SC4 to an external power source (wall outlet, car adapter. etc.) via its power cord. The boot animation will be displayed on the LCD screen

Insert batteries: The SC4 features four independently controlled charging slots. Insert batteries of supported types into each slot according to the polarity marks on the slot. After battery installation, the SC4 begins charging and presents Battery Status by "Good" or "Poor", Internal Resistance, Charging Current, Battery Voltage, Charged Volume and Charging Time on the LCD screen.

Battery inspection and error report: The SC4 has reverse polarity protection and anti-short circuiting

If there are batteries inserted with polarity reversed or short-circuited, the LCD screen of relevant channel will indicate "FF FF" and the power level display will blink to notify the user of an error

Smart charging: The SC4 can choose appropriate charging currents based on intelligent detection about battery types and capacities. Manual charging current selection is also available. The SC4 is compatible with:

- 1) 3.7V Li-ion rechargeable batteries
- 2) 3.8V Li-ion rechargeable batteries (4.35V±1% after fully charged)
- 1.2V Ni-MH/Ni-Cd rechargeable batteries
- 4) 3 2V LiFePO4 hatteries

Default Settings

The default settings (not manually configured) for the SC4 are:

- For Li-ion batteries with large capacity (>1200mAh), the default current is 2000mA, 4.2V±1%.
- For Li-ion batteries with small capacity (<1200mAh), the default current is 500mA, 4.2V±1%.
- For Ni-MH/Ni-Cd batteries, the default current is 500mA, 1.48V±1%.

Note: The SC4 can automatically select charging modes for Ni-MH batteries and 3.7V Li-ion batteries. However, LiFePO4 batteries and 3.8V Li-ion batteries require manual settings on charging cut-off voltages.

For the battery which length is >60mm (2.4"), the SC4 automatically identifies its capacity as >1200mAh.

Key Switches

During charging, press the C switch to cycle through the charging states of 4 channels; Press the V switch to display Battery Status, Internal Resistance, Charging Current, Battery Voltage, Charged Volume and Charging

Holding the C switch will enter the Manual Settings Mode; whilst holding the V switch will prioritize CH1 and

After entering the Manual Settings Mode, press the C switch to alternate CHG. MODE, CHANNEL STATUS and the Settings Mode of the next channel:

Press the V switch to select Charging Voltage in CHG. MODE and Charging Current in CHANNEL STATUS; Hold the V switch to increase Charging Current in CHANNEL STATUS: Hold the C switch to exit the Manual

Charging Voltage Settings

- Step 1: During charging, press the C switch to select channel and hold down the C switch to enter the settings of selected channels
- Step 2: After entering Settings Mode, press the C switch again till the CHG. MODE is showed on the screen. press V to select voltage (3,7V/4,2V/4,3V), After successful setup, holding down the C switch to begin

Charging Current Settings

Battery Type and Capacity		Default current	Max. charging current
Li-ion batteries	>1200 mAh	2000mA	3000mA
	<1200 mAh	500mA	2000mA
Ni-MH batteries	AA/AAA	500mA	2000mA
	Others	500mA	2000mA

Step 1: The same as above.

- Step 2: After entering the Setting Mode, press the C switch until CHANNEL STATUS is shown on the screen: press or hold the V switch to set the Charging Current from 300mA to 3000mA:
- For large capacity batteries (>1200mAh), the selectable Charging Current ranges from 300mA to 3000mA (steadily increased by 100mA)
- For small capacity batteries (<1200mAh), the selectable Charging Current ranges from 300mA to 2000mA (steadily increased by 100mA)

After the appropriate Charging Current is selected, release the C switch and hold the C switch again to exit Manual Settings Mode and begin charging. "FULL" will appear in the CHANNEL STATUS on screen when charging is fully complete.

- 1. If no further operation is done in 30 seconds in Manual Settings Mode, the SC4 will automatically begin charging with the selected setting
- For large capacity batteries, 300mA-3000mA charging current is selectable; For small capacity batteries, Nitecore suggests to select charging current below 1000mA (depends on the batteries capacity); For Ni-MH/ Ni-Cd batteries (regardless of capacity), 300mA-2000mA is suitable
- 3. Do not charge Ni-MH/NiCd batteries at larger than 0.5C current. Doing so can cause overheat of the

Charging in Priority Function

The CH1 and CH2 can be selected to charge in priority by pressing the C switch to access CH1 or CH2, then hold the V switch to prioritize the chosen channel (CH1 and CH2 can be selected at the same time). If CH1 or CH2 is selected to charge in priority, the other channels automatically begin charging after the battery in CH1 or

Automatically Battery Internal Resistance Detection

With the SC4 switch on and batteries installed, the SC4 automatically detects and displays the Internal Resistance in the CHANNEL STATUS. When the Internal Resistance is below 250mΩ, the LCD screen will indicate GOOD: when it is above 250mQ, the LCD screen will present POOR to indicate Battery Status and suggest to replace the battery (For battery which voltage is higher than 4V, the SC4 will display the default internal resistance 120mQ only)

Power Detection

During charging, SC4 will automatically calculate and display Charged Volume in the CHANNEL STATUS.

Anti-short Circuiting and Reverse Polarity Protection

If there are batteries inserted with polar reversed or short-circuited, the LCD screen of relevant channel will indicate "EE EE" and the power level display will blink.

Energy Saving Function

If there is no operation in 3 minutes, the screen will automatically dim to save energy; if there is any operation, the screen will light again

PID (Proportion Integration Differentiation) System

The PID system will automatically control the charging temperature within the safety limit when charging in a large current.

Battery Activation

The SC4 is capable of activating depleted Li-ion batteries with protective circuit. After battery installation, SC4 will test and activate the battery before charging. When a battery is detected as damaged, the power level over the channel will blink to urge an immediate termination of charging.

Li-ion Battery Recovery

Upon insertion of a OV IMR battery, LCD on the SC4 will blink to indicate non-rechargeable. In this situation, press the C and V switch simultaneously to enter recovery mode, the power level display will gradually increase, Nitecore recommends abandoning this battery if it fails to be recovered after several attemnts. NOTE: When attempting to activate an IMR battery reverse polarity protection is temporarily disabled. Take

special care to ensure batteries are correctly inserted. Failing to do so may result in fire and explosion.

Overtime Charging Protection

The SC4 will separately calculate the charging time of each battery. When the overall charging time exceeds ten hours, it will automatically stop charging and display a fully charged status. This is to prevent possible overheat or even explosion due to battery quality issue

USB Charging

The maximum charging current for the USB output is 2.1A. During charging, the output of USB is inhibited until the batteries are fully charged.

- 1. The charger is restricted to charging Li-ion, IMR, LiFePO4, Ni-MH/Ni-Cd rechargeable batteries only. Never use the charger with other types of batteries as this could result in battery explosion, cracking or leaking. causing property damage and/or personal injury.
- The safe operation temperature for the charger is between -10-40°C, and the safe storage temperature is
- 3. Please charge batteries in accordance with the specifications on the back. Do not charge a battery pack with the charger
- Observe polarity diagrams located on the charger. Always place the battery cells with positive tip facing the Do not leave a working charger unattended. If any malfunction is found, please terminate operation
- immediately, and turn to user manual for instruction.
- 6. The charger is designed for adults. Use of the charger by kids under age must be under supervision. Operation, using or cleaning of the charger may NOT be done by kids aged 8 years or younger.
- Please make sure the correct program and settings are chosen and set. Incorrect program or setting may damage the charger, or cause fire or explosion. Never attempt to charge primary cells such as Alkaline, Zinc-Carbon, Lithium, CR123A, CR2, or any other
- unsupported chemistry due to risk of explosion and fire.
- Do not charge a damaged IMR battery as doing so may lead to charger short-circuit or even explosion. 10. Never charge or discharge any battery having evidence of leakage, expansion/swelling, damaged outer
- wrapper or case, color-change or distortion. 11. Use the original adapter and cord for power supply. To reduce the risk of damage to the power cord, always null by connector rather than the cord. Do not operate the charger if it appears damaged in any way.
- 12. Do not expose the device to direct sunlight, heating devices, open flames; avoid extreme high or extreme low ambient temperatures and sudden temperature changes.
- 13. Please operate the charger in a well-ventilated area. Do not operate or store it in damp area. Keep all the inflammable volatile substances away from operating area.
- 14. Avoid mechanical vibration or shock as these may cause damage to the device
- 15. Do not use short-circuit slots or other parts of the device. Do not allow metal wires or other conductive material into the charger.
- 16. Do not touch hot surfaces. The rechargeable batteries or the device may become hot at full load or high power charging/discharging.
- 17. Do not overcharge or over discharge batteries. Recharge drained batteries as soon as possible.
- 18. Remove all batteries and unplug the charging unit from the power source when not in use.
- 19. Opening, disassembling, modifying, tampering with the unit may invalidate its quarantee, check warranty
- 20. Do not misuse in any way! Use for intended purpose and function only.

Disclaimer

This product is globally insured by Ping An Insurance (Group) Company of China, Ltd. Nitecore shall not be held responsible or liable for any loss, damage or claim of any kind incurred as a result of the failure to obey the instructions provided in this user manual.

Warranty Details

Our authorized dealers and distributors are responsible for warranty service. Should any problem covered under warranty occurs, customers can contact their dealers or distributors in regards to their warranty claims, as long as the product was purchased from an authorized dealer or distributor, NITECORE's Warranty is provided only for products purchased from an authorized source. This applies to all NITECORE products.

Any DOA / defective product can be exchanged for a replacement through a local distributor/dealer within the 15 days of purchase. After 15 days, all defective / malfunctioning NITECORE® products can be repaired free of charge for a period of 12 months (1 year) from the date of purchase.

Beyond 12 months (1 year), a limited warranty applies, covering the cost of labor and maintenance, but not the cost of accessories or replacement parts. 1. The warranty is nullified if the product(s) is/are broken down, reconstructed and/or modified by unauthorized

- 2. damaged from wrong operations (i.e. reserve polarity installation, installation of non-rechargeable batteries) 3. damaged by batteries leakage For the latest information on NITECORE® products and services, please contact a local NITECORE® distributor or
- send an email to service@nitecore.com. * All images, text and statements specified herein this user manual are for reference purpose only. Should any discrepancy occurs between this manual and information specified on www.nitecore.com, information on our official website shall prevail. SYSMAX Innovations Co., Ltd. reserves the rights to interpret and amend the content of this document at any time without prior notice.

Safety Instruction for Lithium-ion Batteries

1. Charging Voltage

Lithium-ion (Li-ion) batteries have strict requirement on voltage control. Charging Li-ion batteries with electric voltage beyond safety standard can lead to battery damage and explosion.

(1) 3.7V Li-ion Batteries/ IMR Batteries 3.7V Li-ion batteries are the most common rechargeable Lithium batteries. The skins of these batteries

are often marked with 3.6V/3.7V signs. If our chargers judge that an inserted battery is a Li-ion battery. the battery will be automatically charged in 4.2V standard charging mode. You do not need extra voltage settings for these types of batteries. (2) 3.8V Li-ion Batteries 3.8V Li-ion batteries are comparatively rare. It usually has a 3.7V mark on its skin. Normally its seller will inform its buyer that it needs to be charged with 4.35V power. When charging this type of battery, please

manually set the charging voltage to 4.3V, otherwise the charger will charge at 4.2V by default, and cannot provide adequate charging voltage

(3) 3 3V LiEoDO4 Rattorios 3,2V LiFePO4 batteries have LiFePO4 and/or 3,2V marks on the skin. Be careful with this type of batteries. Without manual setting, our chargers will charge this type of batteries with 4.2V, and will damage or even explode the battery with excessive charging voltage. You need to manually set the charging voltage to 3.7V for safe charging.

2. Charging Current

For all rechargeable Lithium batteries (including Li-ion, IMR and LiFePO4 batteries), we suggest not using current larger than 1C* for charging. For small capacity batteries, the charging current must be smaller than

*C=Capacity of a battery. For example, 1C in a 2600mAb rechargeable Lithium battery is 2.6A, 1C in a 3400mAh rechargeable Lithium battery is 3.4A.

Excessively large charging current will lead to great amount of heat, and consequently battery damage and

AWarning: Our chargers automatically judge and select charging current by the batteries' length. For some long but small capacity batteries (i.e., 12650, 13650, 14650, 16650), please manually set appropriate charging current (smaller than 1C).

(1) Do not short circuit the battery in any way.

(2) Do not use a 3,7V/3,8V Lithium battery when its voltage is lower than 2,8V, otherwise it can be over-

discharged, and/or prone to explosion at next charging.

(3) We strongly recommend batteries with protective circuit. For batteries without protective circuit (such as

IMR batteries), please stay alert for over-discharge and short circuit. (4) Do not discharge a battery with a discharging current larger than its maximum rated current

4. Long-term Storage

The best storage voltage for 3.7V/3.8V rechargeable Lithium batteries is 3.7V. The voltage is too low or too high can damage your battery during storage. You can discharge a battery to 3.7V, or charge it to 3.7V in a charger before you keep it in long-term storage.

Validation code and QR code on package can be verified on Nitecore website.



1.The charger must be used with Nitecore's official cords. During charging, third party cords can cause malfunction, overheat and even fire on the charger. Damages from using unofficial cords cannot be covered by official warranty.

2. The SC4 is restricted to charging Li-ion, TMR, 3.2V LiFePO4, Ni-MH/Ni-Cd rechargeable hatteries only. Never use the SC4 with other types of hatteries as this could result in hattery explosion, cracking or leaking, causing property damage and/or personal injury.